

Lauder – Excavation not possible, below grade water infiltration
Property line, can't excavate



**Lauder – Excavation not possible, below grade water infiltration
Preparing the surface and removing loose concrete**



**Lauder – Excavation not possible, below grade water infiltration
Before**



Lauder – Excavation not possible, below grade water infiltration
Initial coat of CN2000B®



**Lauder – Excavation not possible, below grade water infiltration
Application by spray**



**Lauder – Excavation not possible, below grade water infiltration
One coat of CN2000C® and CN2000D® (in curing process)**



**Lauder – Excavation not possible, below grade water infiltration
After, final finish**

